



SCFSC RANGE - FLAT SATIN BRUSHED




A031SCFSC
INTERMEDIATE



A011SCFSC
1 GANG 2 WAY



A013SCFSC
2 GANG 2 WAY



A015SCFSC
3 GANG 2 WAY



A017SCFSC
4 GANG 2 WAY



A019SCFSC
6 GANG 2 WAY



A094SCFSC
13A SINGLE SWITCHED
SOCKET D.P.



A092SCFSC

**13A SINGLE SWITCHED
SOCKET + X2 'A' TYPE USB**



A096SCFSC

13A DOUBLE SWITCHED SOCKET D.P.




A096/USB/N/SCFSC

**13A DOUBLE SWITCHED SOCKET + X2 'A+C'
TYPE USB**



A095SCFSC

**13A SINGLE SWITCHED
SOCKET D.P + NEON**



A097SCFSC

**13A DOUBLE SWITCHED SOCKET D.P +
NEON**



A022SCFSC

BELL SWITCH



A113SCFSC
13A D.P. FUSED UNIT




A061SCFSC
20A D.P. SWITCH



A071SCFSC
45A D.P. SWITCH 3X3



A062SCFSC
20A DUAL
FLEXOUTLET



A075SCFSC
45A D.P. COOKER UNIT



A135SCFSC
SHAVER UNIT DUAL
VOLTAGE 115V / 230V



A151SCFSC
1G TELEPHONE



A155SCFSC
1G DATA SOCKET
(RJ45)



A156SCFSC
2G DATA SOCKET
(RJ45)



A159SCFSC
TELEPHONE MASTER
+ DATA (RJ45)



A166SCFSC
SATELITE SOCKET



A167SCFSC
TV LOOPING +
SATELITE SOCKET



A159DTSCFSC
DATA SOCKET (RJ45)
+ TV LOOPING




A160SCFSC
1G TV LOOPING
SOCKET



A170SCFSC
3X3 BLANK PLATE



A171SCFSC
6X3 BLANK PLATE



KNOBSCFSC
2 WAY KNOB SWITCH



KNOBA031SCFSC
2 WAY KNOB SWITCH



A145SCFSC
1 GANG 2 WAY LED DIMMER
5W – 150W



A147SCFSC
3 GANG 2 WAY LED DIMMER
5W – 150W



A146SCFSC
2 GANG 2 WAY LED DIMMER
5W – 150W



A148SCFSC
4 GANG 2 WAY LED DIMMER
5W – 150W



1GSUR/SCFSC
SINGLE SURROUND
PLATE (S/BRUSHED)



2GSUR/SCFSC
DOUBLE SURROUND PLATE
(S/BRUSHED)